

Montgomery County Flow Splitter Plan Notes

Please ensure that the following are on all plans which contain a flow splitting device:

1. Specifically call for the installation of the flow splitter in the Sequence of Construction, and add a sentence saying that the contractor must verify the relationship between the invert of the flow splitter pipe and the invert of the overflow pipe **prior to backfilling around the structure.**
2. Add the actual dimension between the invert of the flow splitter pipe and the invert of the overflow pipe to the detail on the plans.
3. Add a note next to the detail calling for the contractor to verify that dimension **prior to backfilling around the structure**, and to notify the design engineer immediately if there is a discrepancy.